






# **USER'S MANUAL**

**DSC800 SERIES** 



# **CONTENTS**


Description of DSC800 counter	
1. Front panel	1-1
2. Back panel	1-2
3. Wire connection	1-3
4. Description of buttons	1-4
Basic operation	
1.Preset	2-3
2. Recall preset value	2-3
3. Reset(Display Zero)	2-4
4. Half (1/2) function	2-4
5. inch/mm Conversion	2-4
6. INCR/ABS Conversion	2-5
7. Bolt hole circle	2-11
8. Axis setting for bolt hole circle	
(1) Setting as X & Y(2) Setting as X & Z(3) Setting as Y & Z(4) Setting as Dia & Rad	2-15 2-16
9. Error message	2-18

# Function

1. Changing Resolution (SCALE)	
(1) 5 / 1000	3-1
(2) 1 / 1000(3) 5 / 10000	
(4) 5 / 100	3-4
(5) 1 / 100	3-5
2. Changing direction	3-7
3. Rate or Correction (5.rAtE)	3-8
4. Reset function (7.rESEt)	
(1) ABS reset	
(2) Program reset	
5. Testing FND (8.tESt)	3-12
6. Adding up Z & Q axes(10. qAdd)	3-13
7. Pitch setting for Magnetic scale	
(1) Pitch setting for MSOW(2) Pitch setting for MSS	
8. Vibration proof function	
9. Displaying 0.1 or 0.01 unit from 0.001/0.005	3-17
13.Rotary encoder setting	3-18
Lathe function	
1. Summing of two axes	4-1
2. Double counting function	4-2
3. Tool offset	4-3
EDM function	
1. Key operation	5-2
2. Output Signal of DSC-803EDM Counter	5-3
3. How to input numerals	5-4
4. Changing Discharge Directions	5-5
5. To check present value of EDM mode as in normal mode	5-8
Installation of linear scale and trouble shooting	
1. Installation	6-1
2. Trouble shooting	6-6
3. Replacing a fuse	6-7
4. Connectors' information	6-8

# DESCRIPTION OF DSC-800


### 1. Front Panel



Keys	Descripton
1. Display area 2. Axis indication lamp 3. Zero set keys 4. Axis indication key 5. Numbers key 6. Function Key 7. ON/OFF switch 8. Subsidiary display area 9. Function lamp	Diplay the values of X, Y and Z axis Lamp will be on when the axis selected Initializing key To select the axis 0 ~ 9 numbers To begin any function, firstly start with "F" Turn on / off the display unit Display when "ABS" or Bolt hole circle selected Lamp will be on when a function selected


Note) This manual explains every function on the basis of 3-axis display unit (DSC-803).

## 2. Back Panel



Keys	Descripton
1. Main power switch 2. Fuse 3. Connectors for scale 4. GND 5. AC supply power	ON/OFF the main power 220V/1A Connections for X, Y and Z axes Ground connector Connection with a power cord

## 3. Wire connection



## 4. Description of buttons

Key	Name	Description
X <sub>o</sub> Y <sub>o</sub> Z <sub>o</sub>	Axis zero key	Reset present displayed axis
XYZ	Axis (indication) key	Select axis
0~9	Number key	Numbers of 0 ~ 9
•	Dot key	Input the value of decimal point
1/2	+/- key	Changing positive(+) or negative(-) value
ENT	Enter key	"Enter" means completion of the process
<b>▲</b>	Backward / Forward	When using "Menu" or "Function", move by sequence. Use this to look for the number of ABS or Bolt hole circle.
CE	Cancel key	Cancel input processing. Cancel excuting operation. Clear the error.
F	Function key	To use any function, firstly push "F" key
1/2	1/2 key	Divide present value into a half
PRE	Preset Recall	Recall memerized coordinates
ABS	Absolute position	To use ABS at any position
$\bigoplus$	Bolt hole circle	To use Bolt hole circle function
INCH	Mm / inch	Changing mm / inch
•	Error key	To find error of a scale
<b>(</b>	On / Off key	Turn on / off the FND display




# **BASIC OPERATION**

Power ON / OFF


For general use, leave the main switch always ON, use ON/OFF switch of the front side.

System will be on after 3 seconds of turning on.


• Main switch of the rear side




• ON/OFF switch of the front side




ON/OFF switch. If the switch of rear side is on, inside circuit is still working even when this switch is off.



#### 1. Preset



#### 2. Recall preset values




### 3. Reset (Display Zero)

X <sub>o</sub> Y <sub>o</sub> Z <sub>o</sub>	To make each axis zero
Ex.	
Xo       X         Yo       Y         Zo       Z	0.000 0.000 0.000


## 4. 1 / 2 Function (dividing into a half)


X - 1/2		To divide a	value into a half
Ex.) To divide "12.400" into a half			
Input or recall "12.400"	X Y Z	12:400 0000 0000	
X 1/2	X Y Z	6.200 0.000 0.000	


#### 5. inch/mm conversion





#### 6. INCR/ABS Conversion















#### 7. Bolt hole circle



There are 4 factors for Bolt hole circle.

- 1) Radius (R), or Diameter(d)
- 2) The number of holes: d-no
- 3) Start angle: Sph 4) Final angle: Eph

Details for 4 factors (imputable range)


Factors	Available range
Radius(r) or diameter(d)	+8000.999mm or +400.9998inch
The number of holes	2 ~ 99 holes
Start angle (Sph)	0.000 ~ 359.999
Final angle (Eph)	0.001 ~ 999.999



Normal mode

An example of a bolt hole circle

Axis setting = X & Y axis Radius(r) = 10.0The number of holes = 8Start angle =  $0^{\circ}.0^{\circ}$ Final angle =  $360^{\circ}.0^{\circ}$ 



Note

Before setting for bolt hole circle, a datum point should be defined.

Input 4 factors  $\rightarrow$  move worktable  $\rightarrow$  X & Y-axis window display "0.000"  $\rightarrow$  find next hole by pushing  $\blacktriangleright$  key.

By using ( ) keys, the position (or ABS no.) of previous or next hole can be found easily.

Bolt hole circle is unavailable in the 1-axis display unit


Please do not move worktable during inputting factors.

	z 30.100
$X_0$ $Y_0$ $Z_0$	x 0.000
	y 0.000
	z 0.000
$\bigoplus$	x cir rAd
	y 0.000
	z 0.000
	CIR
1 0	x clr rAd
	Y 10.000
	z nono

X


— Blinking


CIR



- NOTE -
- \* Processing direction is counterclockwise.
- \* Final angle should be added 360 to the start angle.

Final angle (°) = Start angle + 360






#### 8. Axis setting for Bolt hole circle

#### 1). Setting as X & Y-axis

		Only availa	ble in 2, 3 and 4-axis display unit.
F	Y Z	7£ E 0.000 0.000	
	X	1rclE 0.000 0.000	
ENT	x <i>(A)</i> Y z	## 4 15 HY 0.000 0.000	
ENT	X	0.000 0.000 0.000	

#### 1). Setting as X & Z-axis




#### 3). Setting as Y & Z-axis

		Only availab	le in DSC-803(3-axis), 804(4-axis) display unit.
F	Y	0.000 0.000 W	
	Y	0000 0000 0000	
ENT	Y	0.000 0.000 0.000	
	x 2.84 Y z	0.000 0.000 0.000	
	x 3.8 H Y z	0.000 0.000	
ENT	X Y Z	0.000 0.000 0.000	

#### 4). Setting as Radius & Diameter

$F \rightarrow \triangleright \rightarrow ENT \rightarrow \triangleright \rightarrow \triangleright$	→ ENT Only av	vailable in DSC-802, 803, 804 display unit.
F	x (LAEE y 0.000 z 0.000	
	x <u>2.c ircle</u> y <u>0.000</u> z <u>0.000</u>	
ENT	x (AH 15 H) y 0.000 z 0.000	<u>7</u>
	x <u>2.8H 15 H 3</u> y <u>0.000</u> z <u>0.000</u>	
	x <u>38H 15 93</u> y <u>0000</u> z <u>0000</u>	$\overline{\mathcal{I}}$
	x 4d 18-c80 y 0000 z 0000	(Bolt note circle)
ENT	x <u>0000</u> y <u>0000</u> z <u>0000</u>	$ \overline{\mathcal{G}} $

#### 9. Error Message



Cause of Error and solution			
Symptom	Cause	Solution	
Inaccuracy	Foreign body in a scale. Lubrication oil in a scale. Loose connection of a scale. No ground. Lubrication in joint of extension cable. Wrong operation for Rate or Resolution. Breakdown of glass, reading head or flexible cable.	Remove the foreign body. Remove the lubrication oil. Tighten up the connectors. It needs grounding. Clean up the joint part. Operate "RATE" or "Resolution" Otherwise, contact your local service.	
No counting	Electric shock from outside. Wrong operaion for input "RATE".	Check the ground. Correct "RATE"	
"OPEN" message	There is no connection. Wire is cut.	Make sure the connection and wire cut. Otherwise, contact your local service.	

# D

# **FUNCTION**

F	All of operation for function starts from F key
F 1. LATHE: Summing function  2. CIRCLE: Bolt hole circle  3. SCALE: Changing resolu  4. DIR: Changing processin  5. RATE: Rate, Correction of	on for lathe (38p)  (22 ~ 24p)  ution  ng direction
6. DIA: Double counting for 7.RESET: Initializing function 8. TEST: FND (Flexible Num	on

# 1. Changing resolution (SCALE)

1) 5/1000mm (3.ScALE) (0.0002 inch)

(0.0002 inch)	
$F \rightarrow \triangleright \rightarrow ENT \rightarrow [$	After applying new resolution, 0.000 will be displayed. Resolution should be set according to the scale's resolution.
F D (Double)	x 35cALE y 0000 z 0000
ENT	x 35cALE Y 5EL AH 15 Z 0000
X	x
ENT	x
5	x 5.000 y 5EL AH 15 z 0.000
ENT	x 0000 y 0000 z 0000

#### 2) 1/1000mm (3.ScALE) (0.00004 inch)

$F \rightarrow \triangleright \rightarrow ENT \rightarrow X$	After applying new resolution, 0.000 will be displayed. Resolution should be set according to the scale's resolu	ıtion
F D (Double)	X 35cALE Y 0000 Z 0000	
ENT	x 35cALE y 5EL AH 15 z 0000	
X	x	
ENT	x	
1	x 1000 y SEL AH 15 z 0000	
ENT	x 0000 y 0000 z 0000	

#### 2)5/10000mm (3.ScALE) (0.00002 inch)

$ \begin{array}{c c} \hline F \rightarrow \triangleright \rightarrow \triangleright \rightarrow ENT \rightarrow X \rightarrow \\ \hline 0 \rightarrow \bullet \rightarrow \end{array} $		After apply The resolu	ing new resolution, 0. tion should be same a	00000 will be displayed. s its scale's.
F  (Double)		<u>0.0000</u> 0.0000		
ENT	x 35c y 5EL z	AH 15 0.0000		
X	Y 5EL	0.0000		
ENT	Y 5EL	0.0000		
0 • 5	X Y SEL Z	0.0000		
ENT	Y	00000 00000 00000		

# 3) 5/100mm (3.ScALE)

(0.002 inch)


(0.002 inch)			
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$		After applyin Resolution s	g new resolution, 0.000 will be displayed. hould be set according to the scale's resolution
F  (Double)	Y	: AL E 0.000 0.000	
ENT	y <u>581</u> z	: AL E . AH 15 . 0.000	
X	x	5.000 AH 15 0.000	
ENT	x Y 5 <i>EL</i> z	5.000 . AH 15 0.000	
5 0	x y <u>5EL</u> z	50000 AH 15 0000	
ENT	X	0.000 0.000 0.000	

#### 4) 1/100mm (3.ScALE)


(0.0004 inch)

$ \begin{array}{c c} \hline F \rightarrow \blacktriangleright \rightarrow \blacktriangleright \rightarrow ENT \rightarrow X \rightarrow ENT \\ \rightarrow 1 \rightarrow 0 \rightarrow ENT \end{array} $		After applyi Resolution	ng new resolution, 0.000 will be displayed. should be set according to the scale's resolution
F D D (Double)	Y	2000 0000 0000	
ENT	x 350 y 5EU z		
X	x y <u>5EL</u> z	5.000 . AH IS 0.000	
ENT	x y <u>5EL</u> z	5.000 AH 15 0.000	
10	x Y <u>5EL</u> z	10.000 . AH 15 0.000	
ENT	X	0.000 0.000 0.000	


#### 2. Changing direction (4.dlr)




#### 3. Rate or Correction (5.rAtE)



#### **Correct or Compensation**





 $\frac{100}{100.4} = 0.996015$ 



FUN

ENT x Scate Y SEL AH IS 0.000 Z FUN

X1000000 X Y SEL AH IS 0.000 Z

FUN


x 40000000 ENT Y SEL AH IS 0.000 Z FUN

x 0.996015 0 • 9 9 6 0 1 5 Y SEL AH IS 0.000 Z FUN


0.000 ENT X 0.000 Υ 0.000 Z

#### 4.Reset function (7.rESEt)


#### 1) ABS Reset (Delete ABS data)



### 2) Program Reset (Delete all saved data)





### 5. Testing FND (8.tESt)



### 6. Adding up Z & Q axes(10. qAdd)

Q-axis:






 $\blacksquare NT \rightarrow \boxed{Q} \rightarrow \boxed{\blacktriangleright} (or \boxed{\blacktriangleleft}) \rightarrow \boxed{ENT}$ 

### 7. Pitch Setting for Magnetic scale

### 1) MSOW type






### **⚠** Notice

- Factory setting is 25mm (for optical glass scale).
- In case of magnetic scale, MSOW is to be 5mm and MSS is to be 2mm.


### 2) Pitch setting for MSS type




### **⚠** Notice

- Factory setting is 25mm (for optical glass scale).
- In case of magnetic scale, MSOW is to be 5mm and MSS is to be 2mm.

### 8. Vibration proof function



### 9. Displaying 0.1or 0.01 unit from 0.001/0.005 (diSP: $0.000 \rightarrow 0.00$ or 0.0)




### 13. S-Type: Rotary encoder setting

### (1) & (2) are necessary but (3) is optional.

- (2) input "PPR"  $\boxed{\mathbf{F}} \rightarrow 3 \text{ (or } \boxed{\mathbf{F}} \times 2 \text{ times}) \rightarrow \boxed{\mathbf{ENT}} \rightarrow \boxed{\mathbf{X}} \text{ (or other axis)} \rightarrow \boxed{\mathbf{ENT}} \rightarrow input PPR \rightarrow \boxed{\mathbf{ENT}}$
- (3) changing decimal point (optional)

F →12 (or ►x 11 times) → ENT → 
$$\mathbf{X}$$
 (or other axis) → ENT →  $input$  "100"(x.x) → ENT or "10"(x.xx)

### (1) Linear → Rotary



- X ENT X LINER SEL AH IS Z 0.000

Z

### (2) input "PPR"



z 0.000 EUI X ENT "5.000" flickering X 5.000

input PPR X [2500 for example) Y

\* PPR: Pulse Per Revolution

ENT

Z	0.000
	FUN
X	0.000
Y	0.000
Z	0.000

FUN

2500.000

AH 15

0000

5.000

8H 15

0.000

Y | 5EL

(3) changing decimal point (digits)

X ENT X 5EL Z

1 0 ENT (100 m will display 0.0)

x 0000 Y 0000 z 0000

To change Rotary—→ Linear do the reverse process. Change from Rotary to Linear by F13.

It is also necessary to change resolution by F3, 1 for 1/1000mm and 5 for 5/1000mm.

FUN


0000

0000


▶ Factory setting is "Linear". When the display is initialized, this mode will go back to "Linear".


## DC

### **LATHE FUNCTION**





### 1. Lathe Summing Function (1.LAthE)







### 2. Double Counting Function (6.dIA)






### 3. Tool Offset








### EDM Function

# D


### **BASIC OPERATION**

### ► How to operate 803EDM



Keys	Name	Description
EDM	EDM	To begin EDM Mode from Normal Mode
SET	SET	To set the discharge direction up or down in normal and EDM mode.
▶,◀	Step Key or Up-Down Key	To move to the next discharging step     To use when discharge ready     To set discharge direction up or down
ENT	ENT	Push ENT after inputting data

### 1. Key Operation



<NOTICE> If you want to repeat the same processing after a discharging cycle, don't forget to push key. Then "1" will be shown in the subsidiary display area.


► <Ex.1> When you input data in EDM mode,


X and Y axis display windows show EDM related information.

- X-axis window: shows 'STEP-1' (to 'STEP-4')
- Y-axis window: shows numerals you will input
- <Ex.2> When you start discharging,

X and Y axis display windows show processing related information.


- X-axis window: shows numerals assigned to each STEP.
- Y-axis window:
  - (1) set as Down: firstly shows numerals which is the smallest in the pre-set values.
  - (2) set as Up: firstly shows numerals which is the biggest in the pre-set values.





- ▶ When discharging of every step is finished, numerals will disappear from the subsidiary display area.
- ▶ If you input values at random regardless of the STEP;
  - (1) In case it was set as UP: the smallest value will be automatically assigned to STEP No.1 and the rest in order.
  - (2) In case it was set as DOWN: the biggest value will be automatically assigned to STEP No.1 and the rest in order.

### 2. Output Signal of DSC-803EDM Coutner




▶ In STEP-1 ~ STEP-3, EDM counter will out a relay signal momentarily but, in SETP-4, the relay signal will be out continuously when Z-axis moves down over the value of STEP-4.


In other words, a relay signal will be out continuously,

- (1) If it has been set as 'UP': when the value of Z-axis is bigger than the value of STEP-4.(2) If it has been set as 'DOWN': when the value of Z-axis is smaller than the value of STEP-4.


### 3. How to input numerals




### 4. Changing Discharge Directions




- ▶ When you set discharge direction 'UP', the value you will input should be bigger than present Z-axis value. In case of 'DOWN', the value should be smaller than the Z-axis value.
- ▶ If the STEP values go down though you set the direction 'UP', please change 'counting direction' from (-) to (+) or reversely.
  - \* 'Counting direction' is for the direction of a Linear Scale, while discharge direction is for the direction of an EDM counter(Z-axis moving)
    - \* How to change 'counting direction' (see "'page 31 for more)
    - 1. Make sure if the counter is in normal mode.
    - 2. Push F button, then select '4.dir' from the menu and push [M] key.
    - 3. Push **z** button. (the axis you want to change directions)
    - 4. Push ▶or ◀ to change present direction to opposite direction.
    - 5. Push Into complete changing directions.






### 5. To check present value of EDM mode as in normal mode



### **⚠** Notice



# INSTALLATION & TROUBLE SHOOTING

### 1. Installation

- 1) Installation and precaution
- ① Display counter should be safely grounded.
- ② Do not put the DRO system around other electrical appliances which could cause electrical noise.
- ③ Be careful not to let contaminates like lubrication oil and chips flow into the scale.
- ④ To insure the highest accuracy possible, install the scales as close as possible to the object being measured or the workplace.
- ⑤ It is strongly recommended to install a protective cover and insure that the reading head can move freely and smoothly.
- ⑥ Glass scales can be broken from any shock. Handle with care.
- ① Use the voltage between 110V and 220V.

### Required Tools for installation


Electric Drill: φ3.5, φ4.3, φ5.2

Tap: M4, M5, M6 Dial Gauge: 1/100 mm

Tap Handle Screwdriver Wrench set .

### Mounting accuracy


Mount a linear scale to be horizontal and perpendicular to each central axis.



### 3) Mounting scale

### (1) Positioning, Drilling, Temporary fixing.


By determining mounting position on mounting surface of machine bed, drill and tap holes. Fix the scale temporarily to the machine table, using the hexagon socket head bolt.



### (2) Mounting


Using dial gauge, measure horizontal angle of A.

- 1 Scales over 1000mm, check alignment and if it is fixed in a proper space.
- 1 If the alignment of A don't be measured with Digital Gauge, facing area of alignment mark is parallel in both direction.





### (3) Head carrier Mounting

Space between a machine bed and a reading head should be 0.1378" (3.5mm)  $\pm$  0.0039"(0.1mm) for JSM, and 0"(0mm) $\pm$ 0.0039"(0.1mm)mm for JSS or JSN.




• The guard needs to be removed after installation.





 With a mark at the end of scale as a datum line, gap between head and scale should be equal.




### 2. Trouble shooing

Trouble	Solution
Power was turned off.	<ul> <li>Make sure  key is turned on.</li> <li>Make sure main power is on.</li> <li>Make sure Fuse has blown out</li> <li>Make sure power corder is connected rightly.</li> </ul>
Fuse blows out frequently	<ul> <li>Make sure supping power is stable or not.</li> <li>Disconnect a scale from the counter and check the connectors.</li> <li>After checking above, call repairing service.</li> </ul>
Power is on but display is turned off	<ul> <li>Cutting fluid or oil can flow into the keyboard.</li> <li>Disconnect a scale from a counter.</li> </ul>
ERROR is shown in the axis window	<ul> <li>Check the connection between a scale and a counter.</li> <li>Check the ground state of a counter.</li> <li>Check the fixing bolts are loosen.</li> <li>Connect the scale with other axis of a counter to see which one is the cause</li> <li>Check backlash of the machine.</li> <li>Check if the scale was broken from being got bent or curved.</li> </ul>
Displayed value is fixed when a scale is moving	<ul> <li>Check "RATE" (32p)</li> <li>Check normal rate is "1000000".</li> <li>Check the connection of a scale and a counter.</li> </ul>
One out of X,Y and Z-axis doesn't work	Connect the scale with other axis of a counter to see which one is the cause
DIA lamp is on	Turn to RAD mode using "Double counting function of lathe" (39p).
Displayed value is double counted	<ul> <li>Check "RATE" (32p).</li> <li>Check normal rate is "1000000".</li> <li>Check if DIA lamp is on, then do correction as below (39p)</li> </ul>
Difference between real value and measured value  Correction of RATE (32p)	■ Real distance
Note	Be careful cutting fluid, oil or dust not to flow into a scale.

 $<sup>\</sup>ensuremath{\,\%\,}$  This product can be modified without previous notice to improve quality.

### 3. Replacing a fuse




Replacing a fuse, 250V 2A. Use a - type screw driver

Kinds	Standard
Rated Voltage	110V ~ 220V
Fuse	250V, 2A

### 4. Connector information


Counter	Scale
5 6 1	
1 PIN: + (+5V) 2 PIN: A 3 PIN: B 4 PIN: Z 5 PIN: -(0V) 6 PIN: Shield	1 PIN : + (+5V) 2 PIN : A 3 PIN : B 4 PIN : Z 5 PIN : - (0V) 6 PIN : Shield

### **PIN & Color**



PIN	Color	Signal
1 PIN	RED	+ (+5V)
2 PIN	YELLOW	A (+4.2V)
3 PIN	WHITE	B (+4.2V)
4 PIN	GREEN	Z (+0.4V)
5 PIN	BLACK	- (+0V)
6 PIN	BLACK SHIELD	Shìeld (GND)

### PIN for DSC-703EDM Counter



### 5. RS232 transmission format

### 1. OUTPUT CODE

RS-232: 115200bps, 8bit data, no parity, 1 stop bit

### 2. DATA FORMAT

Character String: 42 byte Format: (4-axis display)

### 

X,Y,Z,Q: Axis data Start

xxxxxxxxx : X axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

yyyyyyyy : Y axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

zzzzzzzz: Z axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

qqqqqqqq: Q axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

CR : carriage return(0x0d)

LF: line feed(0x0a)

(Ex.) X000132.00Y000001.00Z087234.00Q00123.097®①


X = 123.00, Y=1.00, Z = 87234.00, Q=123.097

®: CR, ①: LF

### 6. NC Scale Pin Assignment

Counter (15-pin)			Cable (9-	pin)	
2 PIN	RX	Green	2 PIN	TX	White
3 PIN	TX	White	3 PIN	RX	Green
5 PIN	GND	Black	5 PIN	GND	Black

### **Linear Scale**



1 PIN	black	Vcc (+) 5V
2 PIN	yellow	A
3 PIN	white	B
4 PIN	green	Ā
5 PIN	brown	B
6 PIN	pink	Z
7 PIN	gray	Z
8 PIN	shield	Shield (GND)
9 PIN	blue	GND (-) 0V





Product	Digital Linear Scale (DRO)	Model	DSC800series
Date of Purchase		Serial number	
Agent		Amount	

SER	VICE	RECORDOR SOME SOME SOME SOME SOME SOME SOME SOME	suggest for two y ulation fo r service g date ar	a limited wears from or the presence center as and the other	varranty against the date of ervation of defects were found, irs below blanks.
		Product Digital Linear Scale (	DRO)	Model	DSC800series
		Date of Purchase		Serial number	
		Agent		Amount	
	KINDS	of DAMAGES			DETAILS
	KINDS	TOT DAWNALS	Wit wa	thin the rranty period	After the warranty period
	Functional or mechanical defects happened in normal operation		Gra Exc	atuitous change	
Damage happened	Defects happened during shipping or installing			Ш	
in normal operation, or functional defect		Recurrence of a trouble		П	
	Repairable	Recurrence of same trouble for over 4 times continuously	II		
	No repairable	In case of stop producing of parts, or other reason		_	Exchange for new model as compensation
	Defect caused f repairing and re	I rom careless handling or modeling.	(	Charged	Charged
Functional defect which caused from mishandling or	Defect caused from repairing by non authorized personnel.			П	П
misuse conducted on purpose by users.	Defect from applying non-allowable Voltage (use only AC 220V)			II	п
	Defect or broken from dropping down when moving it another place, after installation.			11	II.
Others		The cause of trouble is not from product itself but from exterior factor.		II .	П
<ul> <li>In the case that the cause is from the natural calamity.</li> <li>When life span of consumable parts is almost done or over.</li> </ul>			Charged		
lease be informed t			Co.,	Ltd.	



